



CHITUMA AUSTRALIA PTY LTD

**E-TRIKE 26/24
Series II**

OWNER MANUAL

CHITUMA AUSTRALIA PTY LTD

3/6 KLAUER ST SEAFORD VIC
AUSTRALIA 3198

Phone: 61 03 97863982

Fax: 61 03 97852347

E-mail: ebike@optusnet.com.au

www.chitumaelectricbicycles.com.au



Date: 01/01/2015

THANK YOU FOR CHOOSING OUR ELECTRIC ASSISTED TRICYCLE

OUR E-TRIKE CAN BE OPERATED VERY EASILY.IT CAN BE OPERATED BY THE MOTOR ALONE OR BY PEDALING ALONE OR A COMBINATION OF BOTH AT THE SAME TIME.IN ORDER TO GIVE YOU A LONG AND SAFE USAGE PLEASE READ THE INSTRUCTIONS BEFORE USING.

SAFTEY CHECK BEFORE RIDING YOUR BICYCLE

- 1.CHECK AND TIGHTEN ALL NUTS ,BOLTS, STRAPS AND FASTENERS
- 2.CHECK THAT BRAKES OPERATE CORRECTLY
- 3.CHECK TYRES FOR WEAR, DAMAGE AND CORRECT PRESSURES.PRESSURES ARE USUALY WRITTEN ON TYRE WALLS.
- 4.CHECK WHEELS FOR TRUENESS
- 5.CHECK LIGHTS FOR OPERATION AND ADJUSTMENT
- 6.CHECK AUDIABLE WARNING DEVICE [BELL OR HORN

**ALWAYS WEAR AN APPROVED
BICYCLE HELMET AND OBEY THE
ROAD RULES AT ALL TIMES**



YOUR TRICYCLE IS DESIGNED FOR USE
ONLY ON PAVED ROADS OR PATHS
(WHERE THE LAWS PERMIT)

DO NOT USE OFF THESE SURFACES
OPERATION

PERFORM SAFETY CHECKS AND ADJUST SEAT
FOR COMFORTABLE RIDING

THE ROCKER SWITCH ON THROTTLE HANDLE
TURNS THE MOTOR ON OR OFF

SQUEEZE LEFT HAND BRAKE AND ALIGHT TRIKE
FROM SAME SIDE

POSITION YOUR SELF ON TRIKE WITH BOTH FEET
ON THE PEDALS **NOT ON THE GROUND.** USE
HANDBRAKE TO MAINTAIN A STATIONARY POSI-
TION


YOUR TRIKE IS NOW READY TO GO. YOU MAY
EITHER PEDAL OR BY TWISTING THE R/HAND GRIP
BACK

TOWARDS YOU USE THE ELECTRIC MOTOR. THE
FURTHER YOU TWIST THE FASTER YOU WILL
TRAVEL

APPLYING EITHER HANDBRAKE WILL CUT MOTOR
POWER AUTOMATICALLY.

TRIKES REQUIRE YOU TO TURN HANDLE BAR
MUCH MORE THAN A 2WHEEL BIKE AND REQUIRE
YOU TO MANUALLY TURN THE HANDLE BAR BACK
TO THE STRAIGHT AHEAD POSITION OTHERWISE
YOU WILL KEEP TRAVELLING IN CIRCLES

ON /OFF AND PEDAL EFFECT SWITCHES



AFTER ALIGHTING HOLD HANDBRAKE AND TURN ON ON/OFF SWITCH. BATTERY INDICATOR ILL LIGHT . TURN OFF BEFORE DISMOUNTING
 WHEN PEDALLING THE MOTOR WILL CUT IN AND ASSIST YOU .IF YOU DO NOT DESIRE THIS PUSH THE PEDAL EFFECT BUTTON TO TURN OFF
 Hold throttle at desired speed for approx 30secs and it will enter cruise control mode and travel at this speed without touching throttle .touch either brake or throttle to exit cruise control

CHARGING

YOU MUST ONLY USE THE CHARGER THAT WE SUPPLY


DO NOT PLUG KETTLE CORD OR COMPUTOR LEAD INTO BATTERY POWER OUT PLUG

ONLY USE IN A DRY WELL VENTILATED ENVIROMENT .

WITH THE LEAD UNPLUGGED FROM 240V POWER SUPPLY PLUG THE SMALL ROUND PLUG INTO POINT LOCATED ON LEFT HAND SIDE OF BATTERY BOX OR ON SMALL BOX LOCATED IN FRONT BASKET .PLUG 3 PIN PLUG INTO STANDARD HOUSE HOLD POWER SUPPLY AND SWITCH ON.YOU WILL SEE A RED LIGHT ON CHARGER ,THIS INDICATES THE UNIT IS ON AND CHARGING THE BATTERY.WHEN CHARGED LIGHT WILL CHANGE TO GREEN AND CHARGER WILL SWITCH AND GO INTO MAINTENANCE MODE.IT IS ALRIGHT TO LEAVE IT IN THIS MODE FOR A SHORT PERIOD OF TIME BUT WE RECOMMEND THAT YOU TURN IT OFF AND UNPLUG FROM POWER POINT AND BIKE AFTER 12 HOURS

REMEMBER ALWAYS SWITCH OFF AT POWER POINT BEFORE PLUGGING OR UNPLUGGING FROM TRICYCLE

MAXIMUN BATTERY LIFE WILL BE ACHIEVED BY CHARGING EVERY DAY AFTER BEING USED . BATTERIES LEFT IN A SEMI DISCHARGED STATE WILL PREMATURALLY FAIL.



PERIODIC MAINTENANCE

ITEM	500klms	1000klms	1500klms	2000klms
3000klms				
BRAKES	A	A	A	A
ALL CABLES	L	I	L	I
CHAIN	L I	I	L	I
TYRES	I	I	I	I
FRONT FORKS	L I	I	L I	I
PEDAL ASSYS	I	I	I	I
ALL NUTS BOLTS FASTENERS ETC	I	I	I	I

A = ADJUST L= LUBRICATE I = INSPECT FOR WEAR ,TIGHTNESS AND CONDITION

PLEASE NOTE THE ABOVE MAINTENANCE IS A SUGGESTED MINIMUMN AND IS NOT IN PLACE OF DAILY SAFTEY CHECKS PRIOR TO RIDING FOR ADVICE ON BRAKE ADJUSTMENT CHECK WITH YOUR DEALER OR LOCAL BIKE SHOP