



**CHITUMA AUSTRALIA PTY LTD**

3/6 KLAUER ST SEAFORD VIC  
AUSTRALIA 3198

Phone: 1300 681 112

Fax: 61 03 97852347

E-mail: [ebike@optusnet.com.au](mailto:ebike@optusnet.com.au)

[www.chitumaelectricbicycles.com.au](http://www.chitumaelectricbicycles.com.au)

**CHITUMA AUSTRALIA PTY LTD**

# ETRIKE-LI 24/20

**ASSEMBLY GUIDE**  
**RECOMMEND ASSEMBLY CARRIED**  
**OUT BY QUALIFIED BIKE**  
**MECHANIC**



**Date: 01/09/2017**

## ASSEMBLY IS BEST CARRIED OUT BY QUALIFIED BICYCLE MECHANIC

FIRST REMOVE ALL PARTS FROM CARTON AND PLACE  
ON BENCH .REMOVE PROTECTIVE WRAP AND  
INSPECT ALL COMPONENTS




INSERT HANDLE BAR ASSY IN FRONT FORK ,




ALIGN MAKING SURE INSERTION SAFETY MARK IS  
OBSERVED.TIGHTEN WITH 6mm ALLEN KEY

**FIT FRONT MUDGAURD AS PICTURED**



**POSITION FRONT WHEEL IN FORKS WITH WIRING ON RIGHT AND LOCKING TABS BETWEEN FORK AND WHEEL**

**TIGHTEN NUTS FIRMLY AND USE CABLE TIES TO SECURE CABLE AGAINST FORKS .  
FIT SEAT ADJUST TO SUIT .**



**ATTACH PEDALS OBSERVING LEFT AND RIGHT HAND**

## CONNECT AND ADJUST FRONT BRAKES

## INSTALL FRONT FRONT & REAR BASKETS

CHECK ALL NUTS , BOLTS , SCREWS AND OTHER FASTENERS FOR FITMENT AND TIGHTNESS , CHECK BRAKES AND TYRE PRESSURES.  
CHARGE BATTERIES AND TEST RIDE TRICYCLE

## CHARGING

**YOU MUST ONLY USE THE CHARGER THAT WE SUPPLY**  
**DO NOT PLUG KETTLE CORD OR COMPUTOR LEAD INTO BATTERY**  
**POWER OUT PLUG**

**ONLY USE IN A DRY WELL VENTILATED ENVIROMENT .**

WITH THE LEAD UNPLUGGED FROM 240V POWER SUPPLY PLUG THE SMALL ROUND PLUG INTO POINT LOCATED ON RIGHT HAND SIDE OF BATTERY BOX .PLUG 3 PIN PLUG INTO STANDARD HOUSE HOLD POWER SUPPLY AND SWITCH ON.YOU WILL NOTICE A RED LIGHT ON CHARGER ,THIS INDICATES THE UNIT IS ON AND CHARGING THE BATTERY.WHEN CHARGED THIS LIGHT WILL CHANGE TO GREEN AND CHARGER WILL SWITCH AND GO INTO MAINTENANCE MODE.IT IS ALRIGHT TO LEAVE IT IN THIS MODE FOR A SHORT PERIOD OF TIME BUT WE RECOMMEND THAT YOU TURN IT OFF AND UNPLUG FROM POWER POINT AND BIKE AFTER 12HOURS  
**REMEMBER ALWAYS SWITCH OFF AT POWER POINT BEFORE PLUGING OR UNPLUGGING FROM TRICYCLE**

MAXIMUN BATTERY LIFE WILL BE ACHIEVED BY CHARGING EVERY DAY AFTER BEING USED . BATTERIES LEFT IN A SEMI DISCHARGED STATE WILL PREMATURALLY FAIL.



YOU MAY REMOVE BATTERY FOR CHARGING IF REQUIRED BY TILTING SEAT FORWARD  
(LEVER UNDERSEAT MAY BE INITALLY STIFF)  
FIRSTLY MAKE SURE POWER IS TURNED OFF  
USE ON/OFF KEY ITO RELEASE BATTERY LOCK.SLIDE BATTERY UPWARDS . INSTALATION IS SIMPLY THE REVERSE

## PERIODIC MAINTENANCE

ITEM	500klms	1000klms	1500klms	2000klms
BRAKES	A	A	A	A
ALL CABLES	L	I	L	I
CHAIN	L I	I	L	I
TYRES	I	I	I	I
FRONT FORKS	L I	I	L I	I
PEDAL ASSYS	I	I	I	I
ALL NUTS BOLTS FASTENERS ETC	I	I	I	I

A = ADJUST L= LUBRICATE I = INSPECT FOR WEAR ,TIGHTNESS AND CONDITION

**PLEASE NOTE THE ABOVE MAINTENANCE IS A SUGGESTED MINIMUMN AND IS NOT IN PLACE OF DAILY SAFTEY CHECKS PRIOR TO RIDING**  
FOR ADVICE ON BRAKE ADJUSTMENT CHECK WITH YOUR DEALER OR LOCAL BIKE SHOP